



austriamicrosystems AG

is now

ams AG

The technical content of this austriamicrosystems application note is still valid.

Contact information:

Headquarters:

ams AG

Tobelbaderstrasse 30

8141 Unterpremstaetten, Austria

Tel: +43 (0) 3136 500 0

e-Mail: ams_sales@ams.com


Please visit our website at www.ams.com

AS5162-EK-SB Socket Board

Socket Board for AS5162 Magnetic Angle Position Sensor

Description

The AS5162-EK-SB socket board is used for quick programming the AS5161 magnetic angle position sensor without soldering due to its ZIF socket. This board can be used in combination with the UART-Interface board and the AS5x6y Software, which provides the chip with the adequate OTP programming commands.



AS5162-EK-SB Socket Board

AS5162 360° Programmable Magnetic Angle Position Sensor with analog output