Product Document

Published by ams OSRAM Group





SL900A

SPI Interface

ams Application Note, Confidential [v1-01] 2014-Jul-22 Page 1 Document Feedback

Content Guide

1	General Description	3
2	SPI Basic Information	3
3	SPI Commands	5
3.1	Write Command	5
3.2	Read Command	7
3.3	Direct Command	8
3.3.1	Direct Command Codes	9
4	Contact Information1	1
5	Copyrights & Disclaimer1	2
6	Revision Information	3

1 General Description

This document provides a detailed description of the SPI interface of the smart label device SL900A. For a complete description

The pins that are required for SPI communication are:

- SCLK: Serial clock signal, generated by the microcontroller,
- SEN: Slave enable signal, generated by the microcontroller,
- DIN: Data input signal, generated by the microcontroller,
- DOUT: Data output signal, generated by SL900A.

Figure 1: SL900A Pinout – SPI Interface Pins highligh



2 SPI Basic Information

The maximum serial clock (SCLK) frequency is 5MHz with a 3V supply and 1MHz with a 1.5V supply. The SPI communication is active when the serial enable (SEN) signal is HIGH. The data is shifted out on the rising edge of the SCLK signal and sampled on the falling edge of the SCLK signal.

DOUT

amu



 $t_{\rm dh}$

Figure 2: SPI Signal Timing Diagram

Figure 1: SPI timing for 3V supply voltage

Symbol	Min	Max	Description
tsc	150µs	-	SEN to first SCLK rising edge setup time
tch	100ns	-	SCLK high period
tcl	100ns	-	SCLK low period
tds	50ns	-	Data setup time
tdh	50ns	-	Data hold time

Figure 2: SPI timing for 1.5V supply voltage

Symbo	ol Min	Max	Description
tsc	150µs	-	SEN to first SCLK rising edge setup time
tch	500ns	-	SCLK high period
t _{cl}	500ns	-	SCLK low period
tds	50ns	-	Data setup time
tdh	50ns	-	Data hold time



3 SPI Commands

All SPI commands are byte-oriented. The first 2 bits in the first byte define the type of the SPI command:

Figure 3: SPI Commands

Command Code	Command Type	Command Description
[0, 0]	Write Command	Writes data to the internal EEPROM. Single byte, or page write is possible.
[0, 1]	Read Command	Read data from the internal EEPROM. Continuous read is possible.
[1, 0]	RFU	Reserved for future use
[1, 1]	Direct Command	Sends a direct command to the device.

3.1 Write Command

The start of the write operation occurs with the rising edge of the DIN signal and is carried out after 8 data bits are sent to the SL900A. The write operation duration is approximately 7.2ms and depends on the frequency of the internal oscillator. The SPI interface ignores all new commands for the entire duration of the write operation.

Figure 4: SPI Write Operation



Figure 5: SPI Write Operation - Single Byte





Trace 1 (yellow):	SEN
Trace 2 (green):	SCLK
Trace 3 (purple):	DIN
Trace 4 (magenta):	DOUT

In page write mode it is possible to write a maximum of 16 bytes in a single write operation and at least 2 bytes which takes approximately 7.2ms. The write operation is started immediately after the SEN signal falls to low, or after the internal address pointer hits the page boundary.

3.2 Read Command





Figure 8: SPI Read Command (Command Type and Adress Part)



Figure 9: SPI Read Command (Data Part)



Trace 1 (yellow):	SEN
Trace 2 (green):	SCLK
Trace 3 (purple):	DIN
Trace 4 (magenta):	DOUT

The read operation is started immediately after the read command is written in. The SL900A signalizes that the data from the EEPROM is ready with the rising edge of the DOUT signal. After the rising edge of the DOUT signal, the microcontroller can read out the data. The SEN signal should be high for the entire duration of the read operation. The falling edge of the SEN signal terminates the read operation. Data can be read out in continuous mode as the address used is the starting address and is incremented automatically after each 8 SCLK periods.

3.3 **Direct Command**



Figure 10: Direct Command - Get External Sensor X, Read FIFO, Read Shelf Life









3.3.1 Direct Command Codes

Figure	13:	SPI	Direct	Commands
--------	-----	-----	--------	----------

Command Code 0b11 C₅-C₀	Command	Description
0b11 00 0000	Reset	All calibration registers are refreshed from the EEPROM. Same function as POR.
0b11 00 0001	Get Temperature	After the DOUT signal goes high 16 additional clock pulses should be sent to read out temperature data.
0b11 00 0010	Get Battery Level	After the DOUT signal goes high 16 additional clock pulses should be sent to read out battery level data.
0b11 00 0011	Get External Sensor 1	After the DOUT signal goes high 16 additional clock pulses should be sent to read out the sensor 1 data.
0b11 00 0100	Get External Sensor 2	After the DOUT signal goes high 16 additional clock pulses should be sent to read out the sensor 2 data.
0b11 00 0101	Start Log	Starts the timer or IRQ mode – first the start time needs to be written using the SPI Write mode.
0b11 00 0110	End Log	Stops the timer or IRQ
0b11 00 0111	Read FIFO Status	Returns the FIFO status (8-bit)
0b11 00 1000	Read Shelf Life	Returns the remaining shelf life (24-bit)
0b11 10 0000	Read FIFO	Reads up to 8 bytes from the FIFO
0b11 10 0001	Write FIFO	Writes up to 8 bytes to the FIFO

Figure 14: Direct Command Example: Get Temperature (Command Part)







Figure 15: Direct Command Example: Get Temperature (Data read-out)

Trace 1 (yellow):	SEN
Trace 2 (green):	SCLK
Trace 3 (purple):	DIN
Trace 4 (magenta):	DOUT

The direct command is initialized immediately after the 8-bit command code is shifted in. The above figures show a Get Temperature direct command. This operation starts the AD conversion on the integrated temperature sensor. The end of conversion is signalized with the rising edge on DIN signal. The 16-bit data can be read out after the rising edge of the DOUT signal. The SEN signal has to be high for the complete duration of the direct command.

4 Contact Information

Buy our products or get free samples online at: www.ams.com/ICdirect

Technical Support is available at: www.ams.com/Technical-Support

Provide feedback about this document at: www.ams.com/Document-Feedback

For further information and requests, e-mail us at: ams_sales@ams.com

For sales offices, distributors and representatives, please visit: www.ams.com/contact

Headquarters ams AG Tobelbaderstrasse 30 8141 Unterpremstaetten Austria, Europe

Tel: +43 (0) 3136 500 0 Website: www.ams.com

5 Copyrights & Disclaimer

Copyright ams AG, Tobelbader Strasse 30, 8141 Unterpremstaetten, Austria-Europe. Trademarks Registered. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

Information in this document is believed to be accurate and reliable. However, ams AG does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

Applications that are described herein are for illustrative purposes only. ams AG makes no representation or warranty that such applications will be appropriate for the specified use without further testing or modification. ams AG takes no responsibility for the design, operation and testing of the applications and end-products as well as assistance with the applications or end-product designs when using ams AG products. ams AG is not liable for the suitability and fit of ams AG products in applications and end-products planned.

ams AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data or applications described herein. No obligation or liability to recipient or any third party shall arise or flow out of ams AG rendering of technical or other services.

ams AG reserves the right to change information in this document at any time and without notice.

6 Revision Information

Changes from 1-00 (2013-Apr-19) to current revision 1-01 (2014-Jul-22)	Page
Update to corporate format	1-11

Note: Page numbers for the previous version may differ from page numbers in the current revision.