

Product Document



Application Note

AN001051

Auto Gain, Optimization and Correction

AS7343 Evaluation Kit

v1-00 • 2022-Aug-24

Content Guide

1	Introduction	3	3.1	Search for Gain Between Saturation and Noise.....	14
2	Auto-Algorithm to Optimize Parameters.....	6	3.2	While Loop for Searching Auto Gain	15
2.1	Steps in the Algorithm – Search for Auto-Gain	6	3.3	Calculation of Optimized Gain Closer to Maximum Limit	17
2.2	Steps in the Algorithm – Calculation with Auto-Gain	8	4	Revision Information	20
2.3	Possible Extension: Auto-TINT	9	5	Additional Documents.....	21
2.4	Correction Gain	10	6	Legal Information.....	22
3	Appendix	14			

1 Introduction

The aim of Auto Gain and optimization is to automatically find the best (maximum possible) parameter options for the Gain, to measure the maximum optimized raw value in a defined range, with which the best possible sensor results can be achieved. This can be achieved with parameter levels that are adapted to the lighting situation. The algorithm calculates the best parameters based on a sample measurement and thus always ensures a maximum adapted resolution. When using different parameter stages, e.g. Gain, minimal nonlinearity occurs, i.e. due to manufacturing tolerances in semiconductor production, the stages differ slightly from each other after normalization. These deviations can be corrected individually or loosely - if the deviations lead to errors that violate the specification.



Suggestions

- ✓ Avoid measuring noise and saturation.
- ✓ Use the full dynamic sensor to increase the sensor sensitivity.
- ✓ Use the optimal parameters in the setup to get the highest accuracy.
- ✓ Adapt the integration time to the available measurement time.
- ✓ Use the Gain to adapt and optimize the counts.
- ✓ Consider the dependence of counts from the parameter setup – normalize the counts before use.
- ✓ Correct production-related nonlinearities during high accuracy, if needed.

Read all the technical notes regarding Gain and Integration Time (TINT) settings, saturation, dynamic and working range, accuracy and linearities in the datasheet [1], software manual [2], and application notes [3]. Consider any limitations in using gains and integration times in automatic processes. Check beforehand if possible nonlinearities of different amplifications by Gain and integration times meet the accuracy requirements of the application or have to be corrected. Information about this is in the datasheet or must be found via tests. The GUI in the EVK demonstrates all the settings of the ADC parameters and allows both automatic use and individual setting. Saturation is displayed, the retention of optimal ADC results - the counts - is not displayed. However, the higher the count, the better the resolution and accuracy, assuming no saturation. It should also be noted that saturation occurs as a function of the set integration time for Full-Scale Range (FSR = max. Counts in Figure 1).

Figure 1:
Relationship Between Setting TINT - FSR/Saturation and Max. Counts

TINT (ms)	f (kHz)	Resolution (bit)	Counts
0,0056	180,00000	1	2
0,0111	90,00000	2	4
0,0222	45,00000	3	8
0,0444	22,50000	4	16
0,0889	11,25000	5	32
0,1778	5,62500	6	64
0,3556	2,81250	7	128
0,7111	1,40625	8	256
1,4222	0,70313	9	512
2,8444	0,35156	10	1 024
5,6889	0,17578	11	2 048
11,3778	0,08789	12	4 096
22,7556	0,04395	13	8 192
45,5111	0,02197	14	16 384
91,0222	0,01099	15	32 768
182,0444	0,00549	16	65 536
364,0889	0,00275	16	65 536

In the main GUI, by default, Auto Gain is ON. Optimization of the Gain is enabled by checking “Max AGAIN” and denoting the maximum Gain value to be considered in the list box besides the checkbox. Similarly, optimization of Integration Time is enabled by checking “Max TINT” and mentioning the maximum value to consider in the drop-down list. The Gain and time should be checked separately for optimization. Either can also be used automatically or fixed individually and separately. Disable the “Optimized Gain Detection” after taking one measurement, as it keeps changing the parameter values for measurement - to achieve an optimized raw value in each measurement if they are enabled.

The following equation describes the algorithm of the Auto-Procedure. The results of this procedure are always the adjusted parameters, Gain and TINT, which should lead to optimal Raw_Counts, if the situation allows it. Therefore, Raw_Counts always refer to the adjusted parameters and must be normalized into a form independent of the parameters (Basic_Counts - see [2] or [3] chapter 2.1).

Equation 1:

$$Basic_Counts = \frac{Raw_Counts}{(Gain \times Integration\ Time)}$$

The GUI always displays in the results and tables the Raw_Counts, Basic_Counts and Corrected_Counts.

Equation 2:

$$Corrected_Counts = Correction_Values * (Basic_Counts - Offset)$$

The Corrected_Counts are calculated and the corrected Basic_Counts consider static and linear shifts from the application or sensor. Corrections are briefly described in this document to correct any nonlinearities that may occur. All the steps described here can be performed in the GUI of the EVK and are described in detail in [2].

2 Auto-Algorithm to Optimize Parameters

The steps in Auto Gain optimization are divided into sections. One part contains the Auto Gain, and the second part optimizes the derived Auto Gain. In the Auto Gain section, Gain between the maximum and minimum range is automatically calculated by the results of the test measurement. Therefore, the sensor's raw value is placed as close to the maximum as possible, without saturation. Here, only the optimization of the Gain is shown as an automatic algorithm. The adjustment of the integration time is similar and is explained and shown as a simple formula. Note that all Gain and Integration Time settings in sum always affect all sensor channels. That is, the channel with the highest sensitivity determines the tuning of the parameters for all the channels.

2.1 Steps in the Algorithm – Search for Auto-Gain

1. The middle Gain value is calculated from the maximum possible Gain for optimization (maxOptGain) and taken as the currentGain.

```
currentGain = (byte)(maxOptGain / 2.0 + 0.5);
```

2. If currentGain is greater than the given maxGain (user given maximum Gain for optimization, selMaxOptGain), currentGain will be equal to the given maxGain.

```
maxGain = selMaxOptGain;
```

```
if (currentGain > maxGain)
```

```
{    currentGain = maxGain;}
```

3. Inside the while loop, the Gain of the device is set to currentGain. Then, it reads out the raw measurement and checks the saturation or noise state of the raw value measurements. If any of the conditions are true, it will enter the corresponding loop.

If the raw value is above the maximum range of the raw values (RawValueStates.Saturation) Gain correction is made by reducing the Gain by half of the currentGain using the algorithm below.

```
while (true)
```

```
{    _sensor.setGain(currentGain);
```

```
        rawValueState = CheckRawValues(ref checkState, ref rawVal, ref basicVal,  
                                        ref corrVal);
```

```
        measureCount++;
```

```
        if (rawValueState == RawValueStates.Saturation)
```

```
{if (currentGain == 0)

    {break;}

    // Set the saturation gain flag

    if (currentGain < saturationGain)

        {saturationGain = currentGain}

    // set new gain value by reducing to half of current gain
    // by right shift method

    currentGain >>= 1;}
```

4. If the raw value is below the minimum range of raw values (RawValueStates.Noise), the Gain correction is made by increasing the Gain when it is in a noise state, as shown in the algorithm below.

```
else if (rawValueState == RawValueStates.Noise)

    {// in case of low gain value use the middle between
      // max and current gain

      if (currentGain == maxGain)

          {break;}

      newGain = (byte)((maxGain + currentGain) / 2.0 + 0.5);

      if (newGain == currentGain)

          {newGain++;}

      // check if new gain value greater than saturation gain

      if (newGain >= saturationGain)

          {break;}

      // currentGain takes the newGain

      currentGain = newGain;}
```

5. If the raw value is not above the maximum range of raw values (RawValueStates.Saturation) and below the minimum range of raw values (RawValueStates.Noise), no Gain correction is made.

```
else
```



```
{break;}}
```

6. If the rawValueState is still in saturation, optimization is not possible. The error is handled in the method below.

```
if (rawValueState == RawValueStates.Saturation)

{errorText = "Optimization not possible due to saturation";

return errorcode;}
```

2.2 Steps in the Algorithm – Calculation with Auto-Gain

As discussed in chapter 2.1, now we have a Gain, which reads raw values between saturation and noise. The next step is to calculate an optimized Gain in such a way that the raw values are closer to the maxRawVal limit.

1. The maximum value of the current raw value is taken from the measured raw values. The range of the maximum raw value and minimum raw value is calculated based on the parameters below.

```
currentRawVal = rawVal.Max();

maxRawVal = _sensor.MaxCounts * _maximumAdcRange;

minRawVal = _sensor.MaxCounts * _minimumAdcRange;
```

Where,

_sensor.MaxCounts: the maximum number of counts for the current ATIME and ASTEP value.

_maximumAdcRange: 0.90

_minimumAdcRange: 0.50

2. The logarithmic value of maxRawVal divided by currentRawvalue is calculated with a base of two. This value is then rounded to the largest integer, less than or equal to that value.

```
diffGain = (int)Math.Floor(Math.Log(maxRawVal / currentRawVal, 2));
```

3. Considering an example of this calculation, the maximumRaw value is 50000, and the currentRawvalue is 30000. The idea behind the above step is to scale 30000 to reach closer to 50000. Since the Gain in the AS7343 is a multiple of two, the base of the calculation is 2.

Equation 3:

$$30000 \times 2^x = 50000$$

$$X = \log_2 \left(\frac{\text{maxRawvalue}}{\text{CurrentRawValue}} \right)$$

$$X = \log_2 \left(\frac{50000}{30000} \right)$$

4. When the currentGain added to the diffGain is greater than the maxGain (user-given maximum Gain for optimization), the diffGain is calculated as the difference between maxGain and currentGain.

```
if (currentGain + diffGain > maxGain)
{diffGain = maxGain - currentGain;}
```

5. When the currentGain added to the diffGain is less than zero, the diffGain is calculated as the difference between zero and currentGain.

```
if (currentGain + diffGain < 0)
{diffGain = 0 - currentGain;}
```

6. If the diffGain is greater than or equal to zero, the currentRawValue is incremented by a left shift of diffGain times. Alternatively, if the difference in Gain is negative, the currentRawValue is decremented by a right shift of (-)diffGain times.

```
currentRawVal = (UInt16)( diffGain >= 0
                        ? currentRawVal << diffGain
                        : currentRawVal >> -diffGain);
```

7. Then, currentGain is added with the calculated diffGain.

```
currentGain = (byte)((int)currentGain + diffGain);
```

8. Optimized Gain is then set as the Gain. Finally, the raw value measurement with the optimized Gain is made.

```
_sensor.setGain(currentGain);

//measurement with optimized values

getMeasurementValues(ref checkState, ref rawVal, ref basicVal, ref corrVal);
```

2.3 Possible Extension: Auto-TINT

Gains can only be increased by a factor of 2. This means that the Gain adaptation is very limited - to optimally fit the counts into the dynamic range up to 16 bits (Full-Scale Range = 2^{16} Counts => 65535 Counts). If the control requirement with the Gain is exhausted, the integration time can be used for further optimization. The background is such that the integration time can be increased in {(ATIME

+ 1) x (ASTEP + 1) x 2.78 μ s}¹ steps, which also leads to higher counts, higher resolution, and, in the case of an increased signal/noise ratio, to higher accuracy.

Example:

A measurement with Gain = 128 and TINT = 182 ms (= FSR with max. 65535 counts) gives a result (the channel with the highest count number) of 5000 counts. Via Gain optimization, it can be calculated that an increase to Gain = 1024, would then bring a count number of about 40000. A Gain with one step higher would lead to saturation (=80000 > 65535). However, the result of the Gain optimization uses only 2/3 of the potential dynamic range (FSR). Increasing the Integration Time could further increase the counts, e.g. to FSR * 0.8 (80% of the sensor dynamics at defined integration time). The Integration Time to be extended, which must be added to the previously defined integration time, can be calculated using the following formula:

Equation 4:

$$TINT_{increase} = 2^{\min\left(\log\left(\frac{TINT}{\left(\frac{2}{720}\right)}, 2\right); 16\right) \times 0.8 - Counts_{expected}} \times \frac{2}{720}$$

Where,

- $Counts_{expected}$ is 40000 here – the expected counts after Gain optimization.
- FSR is Full Scale Range by TINT is 182 ms here.
- 0.8 is defined as 80% of FSR and represents a defined limitation as a maximum for counts.
- $\frac{2}{720}$ is the numerical value in μ s, which is needed to integrate 1 bit.

In the example, the increase leads to adding 35 ms to the previously set integration time of 182 ms.

This leads to an optimized setup of the parameters TINT = 217 ms at Gain = 1024, which would mathematically result in 52428 counts, i.e. 80% of FSR = 65535. Thus, the sensor dynamics are fully implemented within the set limits.

If this formula is included in the software after the Gain optimization, then maximum counts are always achieved. However, there are always changed Integration Times, which may be included several times in the measurement time due to the SMUX configuration.

2.4 Correction Gain

An increase in the Integration Time is linear and does not bring any linearity errors when changing. The gains are different. Different Gain stages use different semiconductor structures on the chip and are therefore affected by production-related deviations in the series. A change in Gain as a setup of

¹ Both settings –ATIME and ASTEP – must not be set to “0”.

the ADC by a factor of 2, results in factor 2, changing the number of counts of the ADC. This deviation is very small, individually different, and is called Gain error or nonlinearity. All channels and stages are affected differently. This leads to changes in the channels to each other, which is wrongly interpreted as a spectral shift in further calculations. As long as a Gain is used in the measurement series or cycles, the deviations do not have any effect on the measurement, unless the calibration and measurement use different gain stages. If automatic and optimized gain levels are used, then Gain correction is recommended.

Depending on the test results and accuracy requirements, Gain correction can be performed individually or batch-wise for the sensors, individually for all channels, or on average per Gain stage. Gain tests can be made with the EVK. A stable light source is necessary for this (better to use more than one and calculate the average of multiple light sources). The tests can be done with the GUI using a script (shown in Figure 2) that makes the initialization, controls the protocol file, sets alternative gains, and starts the measurement for each Gain.

The result of this process is a protocol (log, see Figure 3) file for the tests, which includes the Setup, Raw_Counts, Basic_Counts, temperature, etc. These results can be normalized at one Gain for all channels to see the variations (Figure 4) and to get one correction factor for each channel and Gain. Use this matrix as a Lookup Table (LUT as a matrix) to correct the Basic_Counts according to the used Gain and channel. An alternative can be to use the averaged correction factors for all channels of a Gain (LUT as a vector).

Figure 2:
Tracer File For Gain Test

```
/// Trace file for Gain Test
```

```
Autogain off
```

```
AutoTint on
```

```
max_Tint = 2048
```

```
startLog
```

```
gain 0,5
```

```
readsamples 1
```

```
gain 1
```

```
readsamples 1
```

```
gain 1024
```

```
readsamples 1
```

```
gain 2048
```

```
readsamples 1
```

```
stopLog
```

```
saveLog
```

```
clearlog
```

Figure 3:
Protocol File from Gain Test with Basic_Counts

Gain [x]	Basic F1 (400nm)	Basic F2 (424nm)	Basic FZ (450nm)	Basic F3 (473nm)	Basic F4 (514nm)	Basic FY (555nm)	Basic F5 (547nm)	Basic FXL (595nm)	Basic F6 (635nm)	Basic F7 (685nm)	Basic F8 (745nm)	Basic VIS	Basic NIR
0.5	0.00352	0.01367	0.06172	0.04219	0.06602	0.09766	0.02813	0.08086	0.07813	0.03633	0.00430	0.11602	0.00703
1	0.00352	0.01367	0.06172	0.04238	0.06602	0.09785	0.02813	0.08086	0.07813	0.03633	0.00430	0.11582	0.00703
2	0.00352	0.01367	0.06172	0.04258	0.06621	0.09795	0.02822	0.08105	0.07822	0.03633	0.00449	0.11602	0.00732
4	0.00352	0.01382	0.06201	0.04272	0.06646	0.09829	0.02832	0.08135	0.07852	0.03657	0.00454	0.11650	0.00762
8	0.00344	0.01335	0.05991	0.04138	0.06426	0.09514	0.02732	0.07856	0.07571	0.03545	0.00444	0.11250	0.00757

Gain [x]	Basic F1 (400nm)	Basic F2 (424nm)	Basic FZ (450nm)	Basic F3 (473nm)	Basic F4 (514nm)	Basic FY (555nm)	Basic F5 (547nm)	Basic FXL (595nm)	Basic F6 (635nm)	Basic F7 (685nm)	Basic F8 (745nm)	Basic VIS	Basic NIR
16	0.00344	0.01337	0.05991	0.04142	0.06429	0.09522	0.02733	0.07861	0.07576	0.03550	0.00450	0.11256	0.00778
32	0.00346	0.01340	0.06003	0.04154	0.06448	0.09548	0.02742	0.07884	0.07601	0.03567	0.00457	0.11287	0.00800
64	0.00349	0.01348	0.06032	0.04185	0.06491	0.09613	0.02762	0.07936	0.07657	0.03597	0.00466	0.11357	0.00832
128	0.00348	0.01346	0.06017	0.04176	0.06498	0.09595	0.02760	0.07945	0.07652	0.03594	0.00472	0.11307	0.00859
256	0.00355	0.01370	0.06122	0.04268	0.06628	0.09803	0.02815	0.08111	0.07806	0.03673	0.00485	0.11495	0.00898
512	0.00367	0.01419	0.06333	0.04453	0.06899	0.10208	0.02925	0.08447	0.08111	0.03827	0.00506	0.11836	0.00947
1024	0.00350	0.01364	0.06096	0.04120	0.06650	0.09455	0.02795	0.08160	0.07758	0.03528	0.00488	0.11519	0.00913
2048	0.00349	0.01394	0.06229	0.04151	0.06831	0.09428	0.02819	0.08500	0.07838	0.03451	0.00500	0.11571	0.00937

Figure 4:
Normalized Basic_Counts from Gain Test


Gain [x]	Basic F1 (400nm)	Basic F2 (424nm)	Basic FZ (450nm)	Basic F3 (473nm)	Basic F4 (514nm)	Basic FY (555nm)	Basic F5 (547nm)	Basic FXL (595nm)	Basic F6 (635nm)	Basic F7 (685nm)	Basic F8 (745nm)	Basic VIS	Basic NIR
0.5	1.00890	1.01402	1.02318	1.00815	1.01696	1.01591	1.01847	1.01884	1.02029	1.01009	0.92210	1.02157	0.84548
1	1.00890	1.01402	1.02318	1.01283	1.01696	1.01793	1.01847	1.01884	1.02029	1.01009	0.92210	1.01986	0.84548
2	1.00890	1.01402	1.02318	1.01749	1.01998	1.01895	1.02202	1.02129	1.02156	1.01009	0.96395	1.02157	0.88071
4	1.00890	1.02485	1.02803	1.02098	1.02374	1.02251	1.02553	1.02499	1.02539	1.01688	0.97446	1.02588	0.91595
8	0.98766	0.99043	0.99322	0.98891	0.98989	0.98974	0.98928	0.98992	0.98873	0.98565	0.95343	0.99062	0.91005
16	0.98766	0.99140	0.99322	0.98977	0.99045	0.99051	0.98972	0.99054	0.98937	0.98702	0.96652	0.99116	0.93506
32	0.99311	0.99407	0.99514	0.99269	0.99336	0.99324	0.99283	0.99338	0.99263	0.99177	0.98112	0.99384	0.96224
64	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000
128	0.99971	0.99800	0.99755	0.99802	1.00097	0.99818	0.99957	1.00113	0.99939	0.99942	1.01330	0.99561	1.03295
256	1.01750	1.01587	1.01495	1.01993	1.02104	1.01982	1.01941	1.02196	1.01938	1.02135	1.04077	1.01220	1.08033
512	1.05280	1.05221	1.04992	1.06404	1.06281	1.06193	1.05932	1.06435	1.05924	1.06403	1.08648	1.04220	1.13865
1024	1.00545	1.01157	1.01051	0.98454	1.02445	0.98354	1.01206	1.02820	1.01314	0.98081	1.04678	1.01434	1.09764
2048	1.00115	1.03419	1.03271	0.99195	1.05236	0.98082	1.02068	1.07095	1.02365	0.95954	1.07232	1.01890	1.12626

In the Gain test, possibly not all gains can be served with one Integration Time. It makes sense to adapt the Integration Time to the Gain. Before using Auto-Tint, a test should verify that the use of variable integration times does not result in nonlinearity, since these would otherwise be included in the Gain correction.

3 Appendix

3.1 Search for Gain Between Saturation and Noise

Figure 5:
Search for Gain Between Saturation and Noise



3.2 While Loop for Searching Auto Gain

Figure 6:
While Loop for Searching Auto Gain – Part 1






Figure 7:
While Loop for Searching Auto Gain – Part 2



3.3 Calculation of Optimized Gain Closer to Maximum Limit

Figure 8:
Calculation of Optimized Gain Closer to the Maximum Limit – Part 1







Figure 9:
Calculation of Optimized Gain Closer to the Maximum Limit – Part 2



4 Revision Information

Changes from previous version to current revision v1-00	Page
Initial version	all

- Page and figure numbers for the previous version may differ from page and figure numbers in the current revision.
- Correction of typographical errors is not explicitly mentioned.

5 Additional Documents

The following list include a selection of additional documents with more technical details for the AS7343 sensor and its Evaluation Kit. This list is not fixed and it is constantly changing. Ask us for new details.



For further information, please refer to the following documents:

1. ams-OSRAM AG, *AS7343 14-Channel Spectral Sensor (DS001046)*, Datasheet.
2. ams-OSRAM AG, *AS7343 14-Channel Multi-Spectral Sensor for Spectral and Color Measurement (UG001009)*, User Guide.
3. ams-OSRAM AG, *AS7343 Spectral Sensor Calibration Methods*, Application Note.

6 Legal Information

Copyrights & Disclaimer

Copyright ams-OSRAM AG, Tobelbader Strasse 30, 8141 Premstaetten, Austria-Europe. Trademarks Registered. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

Information in this document is believed to be accurate and reliable. However, ams-OSRAM AG does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

Applications that are described herein are for illustrative purposes only. ams-OSRAM AG makes no representation or warranty that such applications will be appropriate for the specified use without further testing or modification. ams-OSRAM AG takes no responsibility for the design, operation and testing of the applications and end-products as well as assistance with the applications or end-product designs when using ams-OSRAM AG products. ams-OSRAM AG is not liable for the suitability and fit of ams-OSRAM AG products in applications and end-products planned.

ams-OSRAM AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data or applications described herein. No obligation or liability to recipient or any third party shall arise or flow out of ams-OSRAM AG rendering of technical or other services.

ams-OSRAM AG reserves the right to change information in this document at any time and without notice.

RoHS Compliant & ams Green Statement

RoHS Compliant: The term RoHS compliant means that ams-OSRAM AG products fully comply with current RoHS directives. Our semiconductor products do not contain any chemicals for all 6 substance categories plus additional 4 substance categories (per amendment EU 2015/863), including the requirement that lead not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, RoHS compliant products are suitable for use in specified lead-free processes.

ams Green (RoHS compliant and no Sb/Br/Cl): ams Green defines that in addition to RoHS compliance, our products are free of Bromine (Br) and Antimony (Sb) based flame retardants (Br or Sb do not exceed 0.1% by weight in homogeneous material) and do not contain Chlorine (Cl not exceed 0.1% by weight in homogeneous material).

Important Information: The information provided in this statement represents ams-OSRAM AG knowledge and belief as of the date that it is provided. ams-OSRAM AG bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. ams-OSRAM AG has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. ams-OSRAM AG and ams-OSRAM AG suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

Headquarters

ams-OSRAM AG
Tobelbader Strasse 30
8141 Premstaetten
Austria, Europe
Tel: +43 (0) 3136 500 0

Please visit our website at www.ams.com

Buy our products or get free samples online at www.ams.com/Products

Technical Support is available at www.ams.com/Technical-Support

Provide feedback about this document at www.ams.com/Document-Feedback

For sales offices, distributors and representatives go to www.ams.com/Contact

For further information and requests, e-mail us at ams_sales@ams.com